



MODI 2

DIGITAL TO ANALOG CONVERTER

IN NORSE MYTHOLOGY, MODI WAS ONE OF THOR'S SONS.
HERE, MODI 2 IS THE LATEST VERSION OF OUR POPULAR USB DAC.
NOW ENHANCED WITH EVEN MORE BUZZWORD COMPLIANCE,
AND A FEW OTHER TWEAKS TO MAKE IT SOUND BETTER.
JUST PLUG IT IN, AND ENJOY! GREAT MUSIC IN NO TIME.

OWNER'S MANUAL

CONNECTIONS



1 Connect your source (usually a computer) to the Modi 2's USB input, helpfully labeled "USB." Use a short, truly USB 2.0-rated cable (2 meters or less.)

2 Connect the two RCA jacks, labeled "R" and "L", to your amplifier, preamplifier, or receiver. You may use long cables—Modi 2's active output stage drives them with ease.

Select the Modi as the audio output device in both Control Panel (Windows) or System Preferences (Mac) AND your audio player software. If you need drivers, they are available at schiit.com/drivers

3 If your computer does not have drivers for Modi 2, and you cannot install drivers (due to grumpy system admins, usually) unplug the USB cable and switch Modi 2 into Simple Mode. Then reconnect the USB cable and proceed. Simple Mode requires no drivers, but limits rates to 24/96.

CONTROLS



1 When the light is on, that means Modi is powered up. That'll happen every time it's plugged into an active USB port. Leaving it on all the time is fine.

2 There is no 2. This is a really simple device. Why don't you have a listen now?

2-YEAR LIMITED WARRANTY

Schiit Audio warrants to the original purchaser that this product shall be free from defects in material and workmanship for two (2) years from the date of purchase. If a defect covered by this warranty occurs during this period, Schiit Audio will repair the defective product, free of charge. Date of purchase will be based on customer receipts, otherwise date of manufacturing will be used.

If you believe you need warranty service, contact us first. Schiit Audio products sent back to us without a Return Authorization (RA) will be returned to the sender without repair. To contact us and obtain an RA, email info@schiit.com.

Warranty Limitations. This warranty shall not apply if a product: (a) is modified or tampered with; (b) is damaged by negligence, accident, unreasonably use, or other causes unrelated to defective materials or workmanship, or (c) has had the serial number altered or removed.

Any implied warranties, including warranties of merchantability and fitness for a particular purpose, are hereby limited in duration to the warranty period of 2 years. In no event shall Schiit Audio be liable for consequential or incidental damages resulting from the breach of any implied or expressed warranties. Some states do not allow these limitations, so they may not apply to you. You may also have other rights which vary from state to state or province to province.



Application for Council Directives 72/23/EEC, 89/336 EEC
Conformity declared for EN60065, EN55022 Class B, EN50082-1



This equipment has been tested and found to
comply with the limits for a Class B digital device,
pursuant to part 15 of the FCC Rules.



S C H I I T

IN THE BOX

- (1) Modi 2
- (4) Stick-On Feet

SCHIIT.COM
INFO@SCHIIT.COM