ITEM	OWNER'S MANUAL			
FOR	MODI 2			
DESCRIPTION	USB RSYNCHRONOUS 24/192 DRC			
MODEL NO	SCH-08-2	REV B	RANDOM NUMBER	₹ FØ3
NOTES	IN NORSE MYTHOLOGY, MODI WAS ONE OF THOR'S SONS. HERE, MODI 2 IS THE LATEST VERSION OF OUR POPULAR USB DAC. NOW ENHANCED WITH EVEN MORE BUZZWORD COMPLIANCE, AND A FEW OTHER TWEAKS TO MAKE IT SOUND BETTER. JUST PLUG IT IN TO VIRTUALLY ANY COMPUTER, AND YOU'LL BE ENJOYING GREAT MUSIC IN NO TIME.			
			. —	ANDIO





AUDIO COMPONENTS ITEM

ON THE BACK



- 1 Connect your computer to the Modi 2's USB input, helpfully labeled "USB." Use a short, truly USB 2.0-rated cable (2 meters or less.)
- 2 Connect the two RCA jacks, labeled "R" and "L", to your amplifier, preamplifier, or receiver. You may use long cables—Modi 2's active output stage drives them with ease.

Select "Schiit Modi 2" as the audio output device in Control Panel (Windows) or System Preferences (Mac.) Modi requires no drivers for Windows, Mac, or Linux computers when in standard mode.

3 If you'd like to play 24/192 content, unplug the USB cable and switch Modi 2 into Expert Mode. You'll have to install drivers on Windows. They're available at schiit.com/drivers.

ITEM

ON THE FRONT



1 When the light is on, that means Modi is powered up. That'll happen every time it's plugged into an active USB port. Leaving it on all the time is fine.

2 There is no 2. This is a really simple device. Why don't you have a listen now?

WHAT'S IN THE BOX

- (1) Modi 2
- (4) Stick-on feet (see above!)
- (0) RCA Cables
- (0) USB Cables

- (0) Headphone driving capability
- (0) Aluminum parts
- (0) Sexy handcrafted chassis
- (0) Free unlimited downloads

- (1) Cheap bag
- (128) Total components
- (1) Robotic assembly
- (1) Human test



Application for Council Directives 72/23/EEC, 89/336 EEC Conformity declared for EN60065, EN55022 Class B, EN50082-1



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

2-YEAR LIMITED WARRANTY


Schiit Audio warrants to the original purchaser that this product shall be free from defects in material and workmanship for two (2) years from the date of purchase. If a defect covered by this warranty occurs during this period, Schiit Audio will repair the defective product, free of charge. Date of purchase will be based on customer receipts, otherwise date of manufacturing will be used.

If you believe you need warranty service, contact us first. Schiit Audio products sent back to us without a Return Authorization (RA) will be returned to the sender without repair. To contact us and obtain an RA, email tech@schiit.com.

Warranty Limitations. This warranty shall not apply if a product: (a) is modified or tampered with; (b) is damaged by negligence, accident, unreasonably use, or other causes unrelated to defective materials or workmanship, or (c) has had the serial number altered or removed.

Any implied warranties, including warranties of merchantability and fitness for a particular purpose, are hereby limited in duration to the warranty period of 2 years. In no event shall Schiit Audio be liable for consequential or incidental damages resulting from the breach of any implied or expressed warranties. Some state do not allow these limitations, so they may not apply to you. You may also have other rights which vary from state to state or province to province.





SCHIIT.COM TECH@SCHIIT.COM