



MODI MULTIBIT

DIGITAL TO ANALOG CONVERTER

IN NORSE MYTHOLOGY, MODI WAS ONE OF THOR'S SONS.

HERE, MODI MULTIBIT IS ONE OF SCHITT'S MODIS.


IT'S QUITE SIMILAR TO A BIFROST MULTIBIT.

BUT WITHOUT ALL THAT CONFUSING UPGRADABILITY.

ENJOY OUR COMBOBURRITO FILTER AND AD5547 DAC!

OWNER'S MANUAL

CONNECTIONS



1 Connect the supplied 16VAC wall-wart. Don't use any other power adapter.

2 Connect your USB source to the Modi Multibit's USB input with a USB 2.0-rated cable, 2M or less in length.

3 Connect your optical source to the optical input jack, using a good Toslink cable, 3M or less.

4 Connect your coax digital source to the coax input jack, using a good RCA cable, 75 ohm preferred.

5 Connect the two RCA jacks, labeled "R" and "L", to your amplifier, preamplifier, or receiver. You may use long cables—Modi Multibit's active output stage drives them with ease.

For USB, select the Modi as the audio output device in Control Panel (Windows) or System Preferences (Mac) AND in your music player software. Windows users may have to install drivers from schiiit.com/drivers

6 Turn it on and enjoy your music!

CONTROLS



1 Press the button to cycle through the three inputs. Just like on Bifrost Multibit. But hey, this is a heck of a lot cheaper. And USB is standard. Did we say this was a great deal?

2 This light turns on when you've selected a USB source. If no USB source is connected, Modi Multibit will skip this input.

3 This light turns on when you've selected an optical source. Simple enough.

4 This light turns on when you've selected a coaxial digital source. But you already knew that.

Note: Modi Multibit flashes all three lights (2, 3, and 4) in sequence for about 20 seconds after you first turn it on to prevent any thumps, bumps, or other weird noises. Once the lights stop flashing, you're ready to use the Modi Multibit.

And that's it. This is a really simple device. Why don't you have a listen now?

2-YEAR LIMITED WARRANTY

Schiit Audio warrants to the original purchaser that this product shall be free from defects in material and workmanship for two (2) years from the date of purchase. If a defect covered by this warranty occurs during this period, Schiit Audio will repair the defective product, free of charge. Date of purchase will be based on customer receipts, otherwise date of manufacturing will be used.

If you believe you need warranty service, contact us first. Schiit Audio products sent back to us without a Return Authorization (RA) will be returned to the sender without repair. To contact us and obtain an RA, email info@schiit.com.

Warranty Limitations. This warranty shall not apply if a product: (a) is modified or tampered with; (b) is damaged by negligence, accident, unreasonably use, or other causes unrelated to defective materials or workmanship, or (c) has had the serial number altered or removed.

Any implied warranties, including warranties of merchantability and fitness for a particular purpose, are hereby limited in duration to the warranty period of 2 years. In no event shall Schiit Audio be liable for consequential or incidental damages resulting from the breach of any implied or expressed warranties. Some states do not allow these limitations, so they may not apply to you. You may also have other rights which vary from state to state or province to province.



This product is in compliance with standards and regulations of the European Community.



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.



S C H I I T

IN THE BOX

- (1) Modi Multibit
- (1) Wall-Wart
- (4) Stick-On Feet

SCHIIT.COM
INFO@SCHIIT.COM